



Technical Tips R3-07-0005-2

Installation direction of runner

Woody's runners are designed to fit the specific ski in which it will be installed. Occasionally, due to the construction of the ski, it may not be clear from the configuration of the runner which end will be inserted into the leading part of the ski. To install the runner incorrectly could result in damage to the sled or personal injury.

The Slim Jim, Dooly and Flat-Top Series Runners that could be confused will always have a 90° angle in the front of the bar. Because the Dooly and Flat-Top Series are built using flat-top material they will have a 30° angle cut at the rear of the runner. The 90° angle is installed in the front of the ski and the 30° cut is installed at the rear of the ski.

